


# Systems supported by ECUreader / ECUdecoder (update from V4,5x to V4,60)

## TRUCKS




























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Daily & TurboDaily	ENGINE MANAGEME	2.3 HPI 16v F1AE0481B	BOSCH EDC 16 Common Rail

# Systems supported by ECUreader / ECUdecoder (update from V4,5x to V4,60)





















## TRUCKS

## Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Axor	BRAKE POWER SUP	1829 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	1833 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	1840 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	1843 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	2529 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	2533 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	2536 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	2540 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	2543 (05-07)	MB Intarder FR
 Axor	CHRONOTACHOGRA	1829 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	1833 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	1840 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	1843 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	2529 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	2533 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	2536 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	2540 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	2543 (05-07)	MB DTCO Tachpgraph
 Axor	SUSPENSION CONTR	1829 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	1833 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	1840 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	1843 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	2529 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	2533 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	2536 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	2540 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	2543 (05-07)	MB NR ECAS

## Systems supported by ECUREADER / ECUDECODER (update from V4,5x to V4,60)



























































### TRUCKS Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Magnum Dxi	ENGINE MANAGEME	460 (07-..)	
 Magnum Dxi	ENGINE MANAGEME	500 (07-..)	
 Magnum Dxi	IMMOBILIZER	460 (07-..)	
 Magnum Dxi	IMMOBILIZER	500 (07-..)	
 Magnum Dxi	ENGINE MANAGEME	460 (07-..)	
 Magnum Dxi	ENGINE MANAGEME	500 (07-..)	
 Magnum Dxi	IMMOBILIZER	460 (07-..)	
 Magnum Dxi	IMMOBILIZER	500 (07-..)	
 Premium Dxi	ENGINE MANAGEME	370 (07-..)	
 Premium Dxi	ENGINE MANAGEME	410 (07-..)	
 Premium Dxi	ENGINE MANAGEME	450 (07-..)	
 Premium Dxi	IMMOBILIZER	370 (07-..)	
 Premium Dxi	IMMOBILIZER	410 (07-..)	
 Premium Dxi	IMMOBILIZER	450 (07-..)	
 Premium Dxi	ENGINE MANAGEME	370 (07-..)	
 Premium Dxi	ENGINE MANAGEME	410 (07-..)	
 Premium Dxi	ENGINE MANAGEME	450 (07-..)	
 Premium Dxi	IMMOBILIZER	370 (07-..)	
 Premium Dxi	IMMOBILIZER	410 (07-..)	
 Premium Dxi	IMMOBILIZER	450 (07-..)	

# Systems supported by ECUreader / ECUdecoder (update from V4,5x to V4,60)

## TRUCKS


























































Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 P-series	AIR BRAKE MANAGE	P230 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P270 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P310 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P340 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P380 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P420 Euro 4 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P420 Euro 5 (08-..)	VIS
 P-series	AIRBAG	P230 (07-08)	CSS
 P-series	AIRBAG	P270 (07-08)	CSS
 P-series	AIRBAG	P310 (07-08)	CSS
 P-series	AIRBAG	P340 (07-08)	CSS
 P-series	AIRBAG	P380 (07-08)	CSS
 P-series	AIRBAG	P420 Euro 4 (07-08)	CSS
 P-series	AIRBAG	P420 Euro 5 (08-..)	CSS
 P-series	ANTITHEFT	P230 (07-08)	LAS
 P-series	ANTITHEFT	P270 (07-08)	LAS
 P-series	ANTITHEFT	P310 (07-08)	LAS
 P-series	ANTITHEFT	P340 (07-08)	LAS
 P-series	ANTITHEFT	P380 (07-08)	LAS
 P-series	ANTITHEFT	P420 Euro 4 (07-08)	LAS
 P-series	ANTITHEFT	P420 Euro 5 (08-..)	LAS
 P-series	AUTOM. TRANSMISSI	P230 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P270 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P310 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P340 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P380 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P420 Euro 4 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P420 Euro 5 (08-..)	GMS Opticruise
 P-series	BRAKE SYS. MANAG	P420 Euro 4 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P420 Euro 5 (08-..)	Brake management system
 P-series	CHASSIS NETWORK	P420 Euro 4 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P420 Euro 5 (08-..)	Body Computer
 P-series	CLIMA	P230 (07-08)	CCS
 P-series	CLIMA	P270 (07-08)	CCS
 P-series	CLIMA	P310 (07-08)	CCS
 P-series	CLIMA	P340 (07-08)	CCS
 P-series	CLIMA	P380 (07-08)	CCS
 P-series	CLIMA	P420 Euro 4 (07-08)	CCS
 P-series	CLIMA	P420 Euro 5 (08-..)	CCS
 P-series	DASHBOARD	P420 Euro 4 (07-08)	Dashboard
 P-series	DASHBOARD	P420 Euro 5 (08-..)	Dashboard
 P-series	ENGINE MANAGEME	P420 Euro 4 (07-08)	EMS
 P-series	ENGINE MANAGEME	P420 Euro 5 (08-..)	EMS
 P-series	HEADLIGHT LEVEL	P230 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P270 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P310 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P340 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P380 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P420 Euro 4 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P420 Euro 5 (08-..)	VIS
 P-series	SUSPENSION CONTR	P230 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P270 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P310 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P340 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P380 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P420 Euro 4 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P420 Euro 5 (08-..)	SMS ECAS
 P-series	AIR BRAKE MANAGE	P230 (07-08)	VIS

# Systems supported by ECUreader / ECUdecoder (update from V4,5x to V4,60)

## TRUCKS



























































Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 P-series	AIR BRAKE MANAGE	P270 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P310 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P340 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P380 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P420 Euro 4 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P420 Euro 5 (08-..)	VIS
 P-series	AIRBAG	P230 (07-08)	CSS
 P-series	AIRBAG	P270 (07-08)	CSS
 P-series	AIRBAG	P310 (07-08)	CSS
 P-series	AIRBAG	P340 (07-08)	CSS
 P-series	AIRBAG	P380 (07-08)	CSS
 P-series	AIRBAG	P420 Euro 4 (07-08)	CSS
 P-series	AIRBAG	P420 Euro 5 (08-..)	CSS
 P-series	ANTITHEFT	P230 (07-08)	LAS
 P-series	ANTITHEFT	P270 (07-08)	LAS
 P-series	ANTITHEFT	P310 (07-08)	LAS
 P-series	ANTITHEFT	P340 (07-08)	LAS
 P-series	ANTITHEFT	P380 (07-08)	LAS
 P-series	ANTITHEFT	P420 Euro 4 (07-08)	LAS
 P-series	ANTITHEFT	P420 Euro 5 (08-..)	LAS
 P-series	AUTOM. TRANSMISSI	P230 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P270 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P310 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P340 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P380 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P420 Euro 4 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P420 Euro 5 (08-..)	GMS Opticruise
 P-series	BRAKE SYS. MANAG	P420 Euro 4 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P420 Euro 5 (08-..)	Brake management system
 P-series	CHASSIS NETWORK	P420 Euro 4 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P420 Euro 5 (08-..)	Body Computer
 P-series	CLIMA	P230 (07-08)	CCS
 P-series	CLIMA	P270 (07-08)	CCS
 P-series	CLIMA	P310 (07-08)	CCS
 P-series	CLIMA	P340 (07-08)	CCS
 P-series	CLIMA	P380 (07-08)	CCS
 P-series	CLIMA	P420 Euro 4 (07-08)	CCS
 P-series	CLIMA	P420 Euro 5 (08-..)	CCS
 P-series	DASHBOARD	P420 Euro 4 (07-08)	Dashboard
 P-series	DASHBOARD	P420 Euro 5 (08-..)	Dashboard
 P-series	ENGINE MANAGEME	P420 Euro 4 (07-08)	EMS
 P-series	ENGINE MANAGEME	P420 Euro 5 (08-..)	EMS
 P-series	HEADLIGHT LEVEL	P230 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P270 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P310 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P340 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P380 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P420 Euro 4 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P420 Euro 5 (08-..)	VIS
 P-series	SUSPENSION CONTR	P230 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P270 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P310 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P340 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P380 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P420 Euro 4 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P420 Euro 5 (08-..)	SMS ECAS
 R-series	AIR BRAKE MANAGE	R230 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R270 (07-08)	VIS

# Systems supported by ECUreader / ECUdecoder (update from V4,5x to V4,60)

## TRUCKS



























































Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	AIR BRAKE MANAGE	R310 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R340 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R380 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R420 Euro 4 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R420 Euro 5 (08-..)	VIS
 R-series	AIR BRAKE MANAGE	R470 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R500 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R560 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R580 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R620 (07-08)	VIS
 R-series	AIRBAG	R230 (07-08)	CSS
 R-series	AIRBAG	R270 (07-08)	CSS
 R-series	AIRBAG	R310 (07-08)	CSS
 R-series	AIRBAG	R340 (07-08)	CSS
 R-series	AIRBAG	R380 (07-08)	CSS
 R-series	AIRBAG	R420 Euro 4 (07-08)	CSS
 R-series	AIRBAG	R420 Euro 5 (08-..)	CSS
 R-series	AIRBAG	R470 (07-08)	CSS
 R-series	AIRBAG	R500 (07-08)	CSS
 R-series	AIRBAG	R560 (07-08)	CSS
 R-series	AIRBAG	R580 (07-08)	CSS
 R-series	AIRBAG	R620 (07-08)	CSS
 R-series	ANTITHEFT	R230 (07-08)	LAS
 R-series	ANTITHEFT	R270 (07-08)	LAS
 R-series	ANTITHEFT	R310 (07-08)	LAS
 R-series	ANTITHEFT	R340 (07-08)	LAS
 R-series	ANTITHEFT	R380 (07-08)	LAS
 R-series	ANTITHEFT	R420 Euro 4 (07-08)	LAS
 R-series	ANTITHEFT	R420 Euro 5 (08-..)	LAS
 R-series	ANTITHEFT	R470 (07-08)	LAS
 R-series	ANTITHEFT	R500 (07-08)	LAS
 R-series	ANTITHEFT	R560 (07-08)	LAS
 R-series	ANTITHEFT	R580 (07-08)	LAS
 R-series	ANTITHEFT	R620 (07-08)	LAS
 R-series	AUTOM. TRANSMISSI	R230 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R270 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R310 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R340 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R380 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R420 Euro 4 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R420 Euro 5 (08-..)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R470 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R500 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R560 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R580 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R620 (07-08)	GMS Opticruise
 R-series	BRAKE SYS. MANAG	R420 Euro 4 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R420 Euro 5 (08-..)	Brake management system
 R-series	CHASSIS NETWORK	R420 Euro 4 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R420 Euro 5 (08-..)	Body Computer
 R-series	CLIMA	R230 (07-08)	CCS
 R-series	CLIMA	R270 (07-08)	CCS
 R-series	CLIMA	R310 (07-08)	CCS
 R-series	CLIMA	R340 (07-08)	CCS
 R-series	CLIMA	R380 (07-08)	CCS
 R-series	CLIMA	R420 Euro 4 (07-08)	CCS
 R-series	CLIMA	R420 Euro 5 (08-..)	CCS
 R-series	CLIMA	R470 (07-08)	CCS

# Systems supported by ECUreader / ECUdecoder (update from V4,5x to V4,60)

## TRUCKS



























































Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	CLIMA	R500 (07-08)	CCS
 R-series	CLIMA	R560 (07-08)	CCS
 R-series	CLIMA	R580 (07-08)	CCS
 R-series	CLIMA	R620 (07-08)	CCS
 R-series	DASHBOARD	R420 Euro 4 (07-08)	Dashboard
 R-series	DASHBOARD	R420 Euro 5 (08-..)	Dashboard
 R-series	ENGINE MANAGEME	R420 Euro 4 (07-08)	EMS
 R-series	ENGINE MANAGEME	R420 Euro 5 (08-..)	EMS
 R-series	HEADLIGHT LEVEL	R230 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R270 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R310 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R340 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R380 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R420 Euro 4 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R420 Euro 5 (08-..)	VIS
 R-series	HEADLIGHT LEVEL	R470 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R500 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R560 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R580 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R620 (07-08)	VIS
 R-series	SUSPENSION CONTR	R230 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R270 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R310 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R340 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R380 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R420 Euro 4 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R420 Euro 5 (08-..)	SMS ECAS
 R-series	SUSPENSION CONTR	R470 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R500 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R560 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R580 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R620 (07-08)	SMS ECAS
 R-series	AIR BRAKE MANAGE	R230 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R270 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R310 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R340 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R380 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R420 Euro 4 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R420 Euro 5 (08-..)	VIS
 R-series	AIR BRAKE MANAGE	R470 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R500 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R560 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R580 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R620 (07-08)	VIS
 R-series	AIRBAG	R230 (07-08)	CSS
 R-series	AIRBAG	R270 (07-08)	CSS
 R-series	AIRBAG	R310 (07-08)	CSS
 R-series	AIRBAG	R340 (07-08)	CSS
 R-series	AIRBAG	R380 (07-08)	CSS
 R-series	AIRBAG	R420 Euro 4 (07-08)	CSS
 R-series	AIRBAG	R420 Euro 5 (08-..)	CSS
 R-series	AIRBAG	R470 (07-08)	CSS
 R-series	AIRBAG	R500 (07-08)	CSS
 R-series	AIRBAG	R560 (07-08)	CSS
 R-series	AIRBAG	R580 (07-08)	CSS
 R-series	AIRBAG	R620 (07-08)	CSS
 R-series	ANTITHEFT	R230 (07-08)	LAS
 R-series	ANTITHEFT	R270 (07-08)	LAS

# Systems supported by ECUreader / ECUdecoder (update from V4,5x to V4,60)

## TRUCKS









Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	ANTITHEFT	R310 (07-08)	LAS
 R-series	ANTITHEFT	R340 (07-08)	LAS
 R-series	ANTITHEFT	R380 (07-08)	LAS
 R-series	ANTITHEFT	R420 Euro 4 (07-08)	LAS
 R-series	ANTITHEFT	R420 Euro 5 (08-..)	LAS
 R-series	ANTITHEFT	R470 (07-08)	LAS
 R-series	ANTITHEFT	R500 (07-08)	LAS
 R-series	ANTITHEFT	R560 (07-08)	LAS
 R-series	ANTITHEFT	R580 (07-08)	LAS
 R-series	ANTITHEFT	R620 (07-08)	LAS
 R-series	AUTOM. TRANSMISSI	R230 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R270 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R310 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R340 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R380 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R420 Euro 4 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R420 Euro 5 (08-..)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R470 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R500 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R560 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R580 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R620 (07-08)	GMS Opticruise
 R-series	BRAKE SYS. MANAG	R420 Euro 4 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R420 Euro 5 (08-..)	Brake management system
 R-series	CHASSIS NETWORK	R420 Euro 4 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R420 Euro 5 (08-..)	Body Computer
 R-series	CLIMA	R230 (07-08)	CCS
 R-series	CLIMA	R270 (07-08)	CCS
 R-series	CLIMA	R310 (07-08)	CCS
 R-series	CLIMA	R340 (07-08)	CCS
 R-series	CLIMA	R380 (07-08)	CCS
 R-series	CLIMA	R420 Euro 4 (07-08)	CCS
 R-series	CLIMA	R420 Euro 5 (08-..)	CCS
 R-series	CLIMA	R470 (07-08)	CCS
 R-series	CLIMA	R500 (07-08)	CCS
 R-series	CLIMA	R560 (07-08)	CCS
 R-series	CLIMA	R580 (07-08)	CCS
 R-series	CLIMA	R620 (07-08)	CCS
 R-series	DASHBOARD	R420 Euro 4 (07-08)	Dashboard
 R-series	DASHBOARD	R420 Euro 5 (08-..)	Dashboard
 R-series	ENGINE MANAGEME	R420 Euro 4 (07-08)	EMS
 R-series	ENGINE MANAGEME	R420 Euro 5 (08-..)	EMS
 R-series	HEADLIGHT LEVEL	R230 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R270 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R310 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R340 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R380 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R420 Euro 4 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R420 Euro 5 (08-..)	VIS
 R-series	HEADLIGHT LEVEL	R470 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R500 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R560 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R580 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R620 (07-08)	VIS
 R-series	SUSPENSION CONTR	R230 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R270 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R310 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R340 (07-08)	SMS ECAS

## Systems supported by ECUreader / ECUdecoder (update from V4,5x to V4,60)

### TRUCKS





Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	SUSPENSION CONTR	R380 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R420 Euro 4 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R420 Euro 5 (08-..)	SMS ECAS
 R-series	SUSPENSION CONTR	R470 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R500 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R560 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R580 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R620 (07-08)	SMS ECAS

## Systems supported by ECUreader / ECUdecoder (update from V4,5x to V4,60)

### TRUCKS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FM12	BRAKE SYS. MANAG	(98-02)	ABS/ATC
 FM12	CHASSIS NETWORK	(98-02)	Vehicle ECU
 FM12	DASHBOARD	(98-02)	Display
 FM12	SUSPENSION CONTR	(98-02)	ECAS